
IDENTIFICATION INFORMATION

VEHICLE IDENTIFICATION AND SERIAL NUMBERS



1. VEHICLE IDENTIFICATION NUMBER


(a) The vehicle identification number is stamped on the vehicle identification number plate and the certification label, as shown in the illustration.

A:

Vehicle Identification Number Plate

B:

Certification Label




2. ENGINE SERIAL NUMBER AND TRANSAXLE SERIAL NUMBER

(a) The engine serial number is stamped on the cylinder block of the engine and the transaxle serial number is stamped on the housing as shown in the illustration.

(1) Engine Serial Number

A:

2GR-FE



(2) Transaxle Serial Number

A:

U151E, U151F