BODY

GENERAL MAINTENANCE

1. TIGHTEN BOLTS AND NUTS ON CHASSIS AND BODY

(a) Tighten all the parts of the chassis when necessary.
- Steering system
- Drive train
- Suspension
- Brake system
- Engine mounting, etc.

(b) Tighten all the parts of the body when necessary.
- Seat belts
- Seats
- Doors and hood
- Body mountings
- Fuel tank
- Exhaust pipe system, etc.

2. REPLACE AIR CONDITIONING FILTER

(a) Remove the glove compartment assembly.
(b) Remove the filter case by holding both sides.
(c) Remove the filter from the filter case.
(d) Replace the filter with a new one.
(e) The installation is in the reverse order of the removal.