INSTALLATION

1. INSTALL VACUUM SWITCHING VALVE ASSEMBLY

(a) Install the vacuum switching valve with the screw.

(b) Install the 2 vacuum hoses and vacuum switching valve connector.

