HOW TO PROCEED WITH TROUBLESHOOTING

The intelligent tester can be used in steps 4, 6, 8 and 9.

1	VEHICLE BROUGHT TO WORKSHOP

NEXT

2	CUSTOMER PROBLEM ANALYSIS

NEXT

3	PASSENGER AIRBAG ON/OFF INDICATOR CHECK

NEXT

4	DTCs CHECK (Present and Past DTCs)

(a) Check for DTCs.

Result

Result	Proceed to
DTC is output.	A
DTC is not output.	B

B → GO TO PROBLEM SYMPTOMS TABLE

A

5	DTCs CHART

NEXT

6	CIRCUIT INSPECTION

NEXT

7	REPAIR

NEXT

8	CLEAR DTCs (Present and Past DTCs)

(a) Clear DTCs.

NEXT

9	DTCs CHECK (Present and Past DTCs)

(a) Check for DTCs.

Result

Result	Proceed to
DTC is not output.	A
DTC is output.	B

B → Go to step 5

A

10	SYMPTOM SIMULATION

(a) Check the passenger airbag ON/OFF indicator condition.

Result

Result	Proceed to
Passenger airbag ON/OFF indicator is operating normally.	A
Passenger airbag ON/OFF indicator ("OFF") and SRS warning light come on.	B

B → Go to step 5

A

11	CONFIRMATION TEST

NEXT

END