DIAGNOSTIC TROUBLE CODE CHART

1. DTCS FOR OCCUPANT CLASSIFICATION SYSTEM

If a trouble code is displayed during the DTC check, check the circuit listed for the code in the table below (proceed to the page listed for that circuit).

HINT:

When DTC B1150/23 is detected as a result of troubleshooting for the airbag system, perform troubleshooting for the Occupant Classification System as shown in the chart below.

Occupant Classification ECU

DTC Code	Detection Item	Trouble Area	See page
B1771	Passenger Side Buckle Switch Circuit Malfunction	1. Front seat inner belt assembly (Passenger side buckle switch) 2. Occupant classification ECU 3. Front seat wire RH	RS-340
B1780	Front Occupant Classification Sensor LH Circuit Malfunction	1. Front seat assembly RH (Front occupant classification sensor LH) 2. Occupant classification ECU 3. Front seat wire RH	RS-346
B1781	Front Occupant Classification Sensor RH Circuit Malfunction	1. Front seat assembly RH (Front occupant classification sensor RH) 2. Occupant classification ECU 3. Front seat wire RH	RS-353
B1782	Rear Occupant Classification Sensor LH Circuit Malfunction	1. Front seat assembly RH (Rear occupant classification sensor LH) 2. Occupant classification ECU 3. Front seat wire RH	RS-360
B1783	Rear Occupant Classification Sensor RH Circuit Malfunction	1. Front seat assembly RH (Front occupant classification sensor RH) 2. Occupant classification ECU 3. Front seat wire RH	RS-367
B1785	Front Occupant Classification Sensor LH Collision Detection	1. Front seat assembly RH (Front occupant classification sensor LH) 2. Occupant classification ECU	RS-374
B1786	Front Occupant Classification Sensor RH Collision Detection	1. Front seat assembly RH (Front occupant classification sensor RH) 2. Occupant classification ECU	RS-378
B1787	Rear Occupant Classification Sensor LH Collision Detection	1. Front seat assembly RH (Rear occupant classification sensor LH) 2. Occupant classification ECU	RS-382
B1788	Rear Occupant Classification Sensor RH Collision Detection	1. Front seat assembly RH (Rear occupant classification sensor RH) 2. Occupant classification ECU	RS-386
B1790	Center Airbag Sensor Assembly Communication Circuit Malfunction	1. Occupant classification ECU 2. Center airbag sensor assembly 3. Floor wire No. 2 4. Front seat wire RH	RS-390
B1793	Occupant Classification Sensor Power Supply Circuit Malfunction	1. Front seat assembly RH (Occupant classification sensors) 2. Occupant classification ECU 3. Front seat wire RH	RS-401

DTC Code	Detection Item	Trouble Area	See page
B1794	Open in Occupant Classification ECU Battery Positive Line	1. Battery 2. ECU-B Fuse 3. Floor wire No. 2 4. Front seat wire RH 5. Occupant classification ECU	RS-408
B1795	Occupant Classification ECU Malfunction	1. Front seat wire RH 2. Front seat inner belt assembly RH (Passenger side buckle switch) 3. Occupant classification ECU	RS-413
B1796	Sleep Operation Failure of Occupant Classification ECU	1. Occupant classification ECU	RS-416