INSTALLATION

1. REMOVE FRONT SEAT INNER BELT ASSEMBLY

HINT:

- Refer to the instructions for reassembly of the front seat assembly (for flat type) (See page SE-43).
- Refer to the instructions for reassembly of the front seat assembly (for manual seat) (See page SE-52).
- Refer to the instructions for reassembly of the front seat assembly (for power seat) (See page SE-62).

(a) Install the front seat inner belt assembly with the nut.

Torque: 42 N*m (430 kgf*cm, 31 ft.*lbf)