SB

REMOVAL

1. **REMOVE REAR SEAT 3 POINT TYPE BELT ASSEMBLY (for 8-Passenger)**
   HINT:
   Refer to the instructions for disassembly of the rear No. 1 seat assembly (for center seat) (See page SE-78).
   (a) Remove the bolt and rear seat 3 point type belt assembly.

2. **REMOVE REAR SEAT 3 POINT TYPE BELT ASSEMBLY (for 7-Passenger)**
   HINT:
   Refer to the instructions for disassembly of the rear No. 1 seat assembly (for captain seat type) (See page SE-69).
   (a) Remove the bolt and rear seat 3 point type belt assembly.

3. **REMOVE REAR SEAT 3 POINT TYPE BELT ASSEMBLY**
   HINT:
   - Refer to the instructions for disassembly of the rear No. 2 seat assembly (for power seat type RH side) (See page SE-117).
   - Refer to the instructions for disassembly of the rear No. 2 seat assembly (for manual seat type RH side) (See page SE-91).

   (a) Remove the bolt and rear seat 3 point type belt assembly.

4. **REMOVE REAR SEAT INNER BELT ASSEMBLY**
   HINT:
   - Refer to the instructions for disassembly of the rear No. 2 seat assembly (for power seat type LH side) (See page SE-99).
   - Refer to the instructions for disassembly of the rear No. 2 seat assembly (for manual seat type LH side) (See page SE-85).

   (a) Remove the bolt and rear seat inner belt assembly.

INSTALLATION

1. **INSTALL REAR SEAT 3 POINT TYPE BELT ASSEMBLY (for 8-Passenger)**
   HINT:
   Refer to the instructions for reassembly of the rear No. 1 seat assembly (for center seat) (See page SE-80).
   (a) Install the rear seat 3 point type belt assembly with the bolt.
   Torque: 42 N*m (430 kgf*cm, 31 ft.*lbf)

2. **INSTALL REAR SEAT 3 POINT TYPE BELT ASSEMBLY (for 7-Passenger)**
   HINT:
   Refer to the instructions for reassembly of the rear No. 1 seat assembly (for captain seat type) (See page SE-72).
   (a) Install the rear seat 3 point type belt assembly with the bolt.
   Torque: 42 N*m (430 kgf*cm, 31 ft.*lbf)

3. **INSTALL REAR SEAT 3 POINT TYPE BELT ASSEMBLY**
   HINT:
   - Refer to the instructions for reassembly of the rear No. 2 seat assembly (for power seat type RH side) (See page SE-126).
   - Refer to the instructions for reassembly of the rear No. 2 seat assembly (for manual seat type RH side) (See page SE-92).

   (a) Install the rear seat 3 point type belt assembly with the bolt.
   Torque: 42 N*m (430 kgf*cm, 31 ft.*lbf)

4. **INSTALL REAR SEAT INNER BELT ASSEMBLY**
   HINT:
   - Refer to the instructions for reassembly of the rear No. 2 seat assembly (for power seat type LH side) (See page SE-108).
   - Refer to the instructions for reassembly of the rear No. 2 seat assembly (for manual seat type LH side) (See page SE-86).

   (a) Install the rear seat inner belt assembly with the bolt.
   Torque: 42 N*m (430 kgf*cm, 31 ft.*lbf)