REMOVAL

1. **REMOVE CENTER REAR SEAT LAP TYPE BELT ASSEMBLY (for 8-Passenger)**
   HINT:
   Refer to the instructions for disassembly of the rear No. 1 seat assembly (for center seat) (See page SE-78).
   (a) Remove the bolt and center seat lap type belt assembly.

2. **REMOVE CENTER REAR NO. 2 SEAT LAP BELT ASSEMBLY WITH INNER**
   HINT:
   - Refer to the instructions for disassembly of the rear No. 2 seat assembly (for power seat type LH side) (See page SE-99).
   - Refer to the instructions for disassembly of the rear No. 2 seat assembly (for manual seat type LH side) (See page SE-85).

   (a) Remove the bolt and center rear No. 2 seat lap belt assembly with inner.

3. **REMOVE REAR NO. 2 SEAT BELT ASSEMBLY INNER**
   HINT:
   - Refer to the instructions for disassembly of the rear No. 2 seat assembly (for power seat type LH side) (See page SE-99).
   - Refer to the instructions for disassembly of the rear No. 2 seat assembly (for manual seat type LH side) (See page SE-85).

   (a) Remove the bolt and rear No. 2 seat belt assembly inner.

INSTALLATION

1. **INSTALL CENTER REAR SEAT LAP TYPE BELT ASSEMBLY (for 8-Passenger)**

   HINT:

   Refer to the instructions for reassembly of the rear No. 1 seat assembly (for center seat) (See page SE-80).

   (a) Install the center rear seat lap type belt assembly with the bolt.

   Torque: 42 N*m (430 kgf*cm, 31 ft.*lbf)

2. **INSTALL CENTER REAR NO. 2 SEAT LAP BELT ASSEMBLY WITH INNER**

   HINT:

   - Refer to the instructions for reassembly of the rear No. 2 seat assembly (for power seat type LH side) (See page SE-108).
   - Refer to the instructions for reassembly of the rear No. 2 seat assembly (for manual seat type LH side) (See page SE-86).

   (a) Install the center rear No. 2 seat lap belt assembly with inner with the bolt.

   Torque: 42 N*m (430 kgf*cm, 31 ft.*lbf)

3. **INSTALL REAR NO. 2 SEAT BELT ASSEMBLY INNER**

   HINT:

   - Refer to the instructions for reassembly of the rear No. 2 seat assembly (for power seat type LH side) (See page SE-108).
   - Refer to the instructions for reassembly of the rear No. 2 seat assembly (for manual seat type LH side) (See page SE-86).

   (a) Install the rear No. 2 seat belt assembly inner with the bolt.

   Torque: 42 N*m (430 kgf*cm, 31 ft.*lbf)