DIAGNOSTIC TROUBLE CODE CHART

If a trouble code is displayed during the DTC check, check the trouble areas listed for that code in the table below and proceed to the appropriate page.

Dynamic Laser Cruise Control System:

DTC Code	Detection Item	Trouble Area	See page
P0500	Vehicle Speed Sensor Malfunction	1. Vehicle speed sensor 2. Vehicle speed sensor signal circuit 3. ECM	CC-67
P0503	Vehicle Speed Sensor "A" Intermittent / Erratic / High	1. Vehicle speed sensor 2. Vehicle speed sensor signal circuit 3. ECM	CC-67
P0571	Brake Switch "A" Circuit	1. Stop light switch 2. Stop light switch circuit 3. ECM	CC-68
P0571	Stop Light Switch Circuit Malfunction	1. BRK relay 2. BRK relay circuit 3. Skid control ECU	CC-71
P0607	Control Module Performance	ECM (This DTC indicates malfunction in ECM. When this DTC is output, it is necessary to replace ECM.)	CC-75
P1570	Radar Sensor Malfunction	Laser sensor	CC-76
P1572	Improper Aiming of Radar Sensor Beam Axis	Laser sensor	CC-77
P1575	Warning Buzzer Malfunction	1. Skid control buzzer 2. Skid control buzzer circuit 3. ABS & traction actuator (Skid control ECU)	CC-78
P1578	Brake System Malfunction	VSC system	CC-79
P1615	Communication Error from Distance Control ECU to ECM	1. Communication circuit 2. Distance control ECU 3. ECM	CC-80
P1616	Communication Error from ECM to Distance Control ECU	1. Communication circuit 2. Distance control ECU 3. ECM	CC-81
P1617	Distance Control ECU Malfunction	Distance control ECU	CC-82
P1630	Communication Error from VSC to ECM	1. Communication circuit 2. ABS & traction actuator (Skid control ECU) 3. ECM	CC-84
P1631	Communication Error from ECM to VSC	1. Communication circuit 2. ECM 3. ABS & traction actuator (Skid control ECU)	CC-85
U0100	Lost Communication with ECM/ PCM "A"	1. Communication circuit 2. ECM 3. Distance control ECU	CC-81
U0100	Lost Communication with ECM/ PCM "A"	1. Communication circuit 2. ECM 3. ABS & traction actuator (Skid control ECU)	CC-85
U0122	Lost Communication with Vehicle Dynamics Control Module	1. Communication circuit 2. ABS & traction actuator (Skid control ECU) 3. ECM	CC-84

DTC Code	Detection Item	Trouble Area	See page
U0123	Communication Error of Yaw Rate Sensor	1. Communication circuit 2. Yaw rate sensor 3. Distance control ECU 4. ECM	CC-86
U0126	Lost Communication with Steering Angle Sensor Module	1. Communication circuit 2. Steering angle sensor 3. Distance control ECU 4. ECM	CC-87
U0235	Lost Communication with Cruise Control Front Distance Range Sensor	1. Communication circuit 2. Laser sensor 3. Distance control ECU	CC-88
U1101	Lost Communication with Distance Control ECU	1. Communication circuit 2. Distance control ECU 3. ECM	CC-80
U1102	Lost Communication with Radar Sensor	1. Communication circuit 2. Laser sensor 3. Distance control ECU	CC-91