

H

I035770E01

PERSONAL LIGHT ASSEMBLY

ON-VEHICLE INSPECTION

1. ROOF CONSOLE BOX ASSEMBLY

(a) Inspect map light assembly resistance.

(1) Check the resistance between the terminals at each switch position as shown in the chart.

Resistance

Switch operation	Tester connection	Specified condition
OFF	-	10 kΩ or higher
DOOR	2 - 3	Below 1 Ω
ON	1 - 1	Below 1 Ω