ROOM LIGHT ASSEMBLY

ON-VEHICLE INSPECTION

1. ROOM LIGHT ASSEMBLY NO.2

(a) Check that the resistance exists between the terminals.

Resistance:

Below 1 Ω

2. INTERIOR DOME LIGHT SWITCH ASSEMBLY

(a) Check that there is resistance between the terminals at each switch position as shown in the chart.

Resistance

Switch operation	Tester connection	Specified condition
OFF	8 - 7 9 - 7 10 - 7	10 kΩ or higher
DOOR	5 - 10 6 - 9 7 - 8	Below 1 Ω
ON	7 - 8 - 9 - 10	Below 1 Ω

(b) Inspect illumination operation.

(1) Connect the battery positive (+) lead to the terminal 4 and the battery negative (-) lead to the terminal 1, and check that the illumination comes on.