VANITY LIGHT

ON-VEHICLE INSPECTION

1. LH VISOR ASSEMBLY

(a) Inspect vanity light resistance.

(1) check that the resistance exists between the terminal 1 and the terminal 2 when the light is operated.

Resistance:

OFF (closed):

10 kΩ or higher

ON (opened):

Below 1 Ω

2. RH VISOR ASSEMBLY

(a) Inspect vanity light resistance.

(1) check that the resistance exists between the terminal 1 and the terminal 2 when the light is operated.

Resistance:

OFF (closed):

10 kΩ or higher

ON (opened):

Below 1 Ω