REAR DOOR COURTESY SWITCH

INSPECTION

1. FRONT DOOR COURTESY LIGHT SWITCH ASSEMBLY

(a) Check that there is resistance between the terminal and the switch body when the switch is operated.

Resistance:

ON (When shaft is pressed):

10 kΩ or higher

OFF (When shaft is not pressed):

Below 1 Ω