WIPER AND WASHER SYSTEM

PRECAUTION

1. PRECAUTION OF WASHER NOZZLE ADJUSTMENT

(a) Do not clean or adjust the washer nozzle with a safety pin, etc. because;
  (1) the washer nozzle tip is made of resin and could be damaged.
  (2) adjustment is not necessary because the washer nozzle is a spray type.

(b) In case the washer nozzle is clogged with wax etc., remove it and clean the nozzle hole with a soft resin brush, etc.

PROBLEM SYMPTOMS TABLE

1. FRONT WIPER AND WASHER SYSTEM

Symptom	Suspected area	See page
Front wipers do not operate.	1. IG1 relay	-
	2. WIP fuse	-
	3. Windshield wiper switch assembly	WW-17
	4. Windshield wiper motor assembly	WW-5
	5. Wire harness or connector	-
Front wipers do not operate in LO or HI.	1. Windshield wiper switch assembly	WW-17
	2. Windshield wiper motor assembly	WW-5
	3. Wire harness or connector	-
Front wipers do not operate in INT.	1. Windshield wiper switch assembly	WW-17
	2. Windshield wiper motor assembly	WW-5
	3. Wire harness or connector	-
Front washer motor does not operate.	1. IG1 relay	-
	2. WSH fuse	-
	3. Windshield wiper switch assembly	WW-17
	4. Front washer motor	WW-19
	5. Wire harness or connector	-
Front wipers do not operate when front washer switch is in the ON position.	1. Windshield wiper switch assembly	WW-17
	2. Windshield wiper motor assembly	WW-5
	3. Wire harness or connector	-
Front washer fluid is not injected.	Washer hose and nozzle	-
When front wiper switch is in HI position, the wiper blade is in contact with the body.	1. Front wiper arm installation position	WW-5
	2. Windshield wiper motor assembly	WW-5
When the front wiper switch is OFF, the wiper blade dose not retract or retract in the wrong position.	1. Front wiper arm installation position	WW-5
	2. Windshield wiper motor assembly	WW-5

2. REAR WIPER AND WASHER SYSTEM

Symptom	Suspected area	See page
Rear wiper does not operate.	1. IG1 relay	-
	2. RR WIP fuse	-
	3. Windshield wiper switch assembly	-
	4. Rear wiper motor and bracket assembly	-
	5. Wire harness or connector	-
Rear wiper does not operate in ON or INT.	1. Windshield wiper switch assembly	-
	2. Rear wiper motor and bracket assembly	-
	3. Wire harness or connector	-
Rear washer motor does not operate.	1. IG1 relay	-
	2. WSH fuse	-
	3. Windshield wiper switch assembly	WW-17
	4. Rear washer motor	WW-20
	5. Wire harness or connector	-
Rear wiper does not operate when rear washer switch is in the ON position (Rear wiper switch is ON side).	1. Windshield wiper switch assembly	WW-17
	2. Rear wiper motor and bracket assembly	WW-12
	3. Wire harness or connector	-
Rear washer fluid is not injected.	Washer hose and nozzle	-
When rear wiper switch is in ON position, the wiper blade is in contact with the body	1. Rear wiper blade installation position	WW-15
	2. Rear wiper motor assembly	WW-12
When the wiper switch is OFF, the wiper blade dose not retract or retract in the wrong position.	1. Rear wiper blade installation position	WW-15
	2. Rear wiper motor assembly	WW-12

3. WASHER FLUID LEVEL WARNING SYSTEM

Symptom	Suspected area	See page
Washer level warning light comes on (Washer fluid level is normal).	1. Level warning switch assembly	-
	2. Combination meter assembly	ME-21
	3. Wire harness or connector	-
Washer level warning light does not come on (Empty the washer fluid in washer tank assembly).	1. Level warning switch assembly	-
	2. Combination meter assembly	ME-21
	3. Wire harness or connector	-