FRONT WASHER MOTOR

ON-VEHICLE INSPECTION

1. INSPECT FRONT WASHER MOTOR

(a) Operation Check

(1) Pour the water into the washer jar with the windshield washer motor and pump installed to the washer jar assembly.

(2) Connect the battery (+) to the terminal 1 of the windshield washer motor and pump assembly, the battery (-) to the terminal 2 of the windshield washer motor and pomp assembly. Check that the water comes out from the washer jar.

