REAR WASHER MOTOR

ON-VEHICLE INSPECTION

1. INSPECT REAR WASHER MOTOR

(a) Pour the water into the washer jar with the rear washer motor assembly installed to the washer jar assembly.

(b) Connect the battery (+) to the terminal 1 of the rear washer motor assembly, the battery (-) to the terminal 2 of the rear washer motor assembly. Check that the water comes out from the washer jar.

