OPERATION CHECK

1. REMOVE CHECK FUNCTION

(a) Check that the key reminder warning buzzer sounds.
  (1) With the driver side door closed, insert the key into the ignition key cylinder and then turn the key to LOCK or ACC.
  (2) Check that the buzzer sounds intermittently if the driver side door is opened.

(b) Check that the key reminder warning buzzer stops.
  (1) Check that the buzzer stops sounding if any of the following operations is performed while the buzzer is sounding:
    - Close the driver side door (front door courtesy light switch is off).
    - Turn the ignition switch ON.
    - Pull out the key from the ignition key cylinder.

PROBLEM SYMPTOMS TABLE

KEY REMINDER WARNING SYSTEM

Symptom	Suspected Area	See page
Key reminder buzzer does not sound	1. Unlock warning switch circuit	DL-84
	2. Front door courtesy light switch circuit (Driver side)	LI-46
	3. Combination meter assembly (Key reminder buzzer)	ME-19
	4. Driver side J/B assembly (Multiplex network body ECU)	-