Sound Quality is Bad Only when CD is Played (Volume is Too Low)

INSPECTION PROCEDURE

1	REPLACE CD WITH ANOTHER AND RECHECK

(a) Replace the CD with another one and recheck.
(1) Check if the problem recurs using another CD.
OK:
Malfunction disappears.

NG → **REPLACE RADIO RECEIVER**

OK

END

CD cannot be Ejected

INSPECTION PROCEDURE

1	**PRESS "EJECT" AND CHECK OPERATION**

(a) Press the CD EJECT switch of the radio receiver for 2 seconds or more and check that the CD is ejected.
OK:
CD is ejected.

NG → **REPLACE RADIO RECEIVER**

OK

2	**REPLACE CD WITH ANOTHER AND RECHECK**

(a) Insert another CD and check if it is ejected.
OK:
CD is ejected.

NG → **REPLACE RADIO RECEIVER**

OK

END