# INSTALLATION

1. INSTALL STEERING PAD SWITCH LH
2. INSTALL HONE BUTTON ASSEMBLY (See page RS-424)
3. INSTALL STEERING WHEEL NO. 3 LOWER COVER (See page RS-425)
4. INSTALL STEERING WHEEL NO. 2 LOWER COVER (See page RS-425)
5. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL
6. INSPECT HONE BUTTON ASSEMBLY (See page RS-425)
7. INSPECT SRS WARNING LIGHT (See page RS-425)