DTC	21-10	Panel Switch Error

DTC	21-11	Touch Switch Error

DTC	23-10	Panel Switch Error

DTC	23-11	Touch Switch Error

DTC	24-10	Panel Switch Error

DTC	24-11	Touch Switch Error

DTC	25-10	Panel Switch Error

DTC	25-11	Touch Switch Error

DESCRIPTION

DTC No.	DTC Detection Condition	Trouble Area
21-10	The panel switch detection circuit has a problem.	Radio and navigation assembly
21-11	The touch panel switch has a problem.	
23-10	The panel switch detection circuit has a problem.	
23-11	The touch panel switch has a problem.	
24-10	The panel switch detection circuit has a problem.	
24-11	The touch panel switch has a problem.	
25-10	The panel switch detection circuit has a problem.	
25-11	The touch panel switch has a problem.	

NS

INSPECTION PROCEDURE

HINT:
After the inspection is completed, clear the DTCs.

1	REPLACE RADIO AND NAVIGATION ASSEMBLY

NEXT

END

DTC	34-10	Error in Picture Circuit

DTC	34-11	No Current in Back-light

DTC	34-12	Excess Current in Back-light

DESCRIPTION

DTC No.	DTC Detection Condition	Trouble Area
34-10	Error in power supply system for picture circuit	Radio and navigation assembly
34-11	Decline in power output from inverter circuit for back-light	
34-12	Excess power output from inverter circuit for back-light	

INSPECTION PROCEDURE

HINT:
After the inspection is completed, clear the DTCs.

1	REPLACE RADIO AND NAVIGATION ASSEMBLY

NEXT

END