CUSTOMIZE PARAMETERS

HINT:
The following items can be customized.
NOTICE:

- **After confirming whether the items requested by the customer are applicable or not for customization, perform customize operations.**
- **Be sure to record the current settings before customizing.**
- **When troubleshooting, make sure that the item in question is not set to "OFF" as a result of customization. (Example: For the symptom "the wireless function does not operate", first check that the wireless function is not set to "OFF", then perform troubleshooting).**

POWER WINDOW

DISPLAY (ITEM)	DEFAULT CONTENTS	CONTENTS	SETTING
IG OFF P/W	ON	After ignition switch OFF, power window control permission output	ON/OFF

PROBLEM SYMPTOMS TABLE

POWER WINDOW CONTROL SYSTEM (W/O JAM PROTECTION)

Symptom	Suspected Area	See page
All power windows do not operate	1. PWR fuse	-
	2. Power window relay (Marking: P/W)	-
	3. Ignition switch	-
	4. Power window regulator master switch	WS-41
	5. Power window regulator motor assembly	WS-43
	6. Wire harness	-
Only one power windows does not operate	1. Power window regulator master switch	WS-41
	2. Power window regulator switch (Front passenger)	WS-43
	3. Power window regulator switch (Rear)	WS-44
	4. Power window regulator motor assembly	WS-45
	5. Wire harness	-
AUTO DOWN function does not operate	1. Power window regulator master switch	WS-41
	2. Power window regulator motor assembly	WS-45
Window lock system does not operate	1. Power window regulator master switch	WS-41
Window cannot be operated after ignition switch OFF	1. Front door courtesy switch assembly	LI-108
	2. Driver side J/B assembly (Multiplex network body ECU)	-