INSTALLATION

1. INSTALL REAR NO. 1 SEAT ASSEMBLY CENTER

(a) Place the seat in the cabin.
NOTICE:
Be careful not to damage the body.

(b) Install the rear seat.

(c) Install the seat belt anchor plate with the bolt.
Torque: 42 N*m (428 kgf*cm, 31 ft.*lbf)

(d) Install the headrest.

(e) When sliding the seat, check that the both sides of the adjuster lock simultaneously.
HINT:
Check that the seat adjuster locks.