INSTALLATION

1. INSTALL REAR NO. 2 SEAT ASSEMBLY RH

(a) Place the rear No. 2 seat assembly RH in the cabin.
NOTICE:
Be careful not to damage the body.

(b) Install the seat with the bolt.
Torque: 29 N*m (296 kgf*cm, 21 ft.*lbf)

(c) Install the locus cable RH with the bolt.
Torque: 29 N*m (296 kgf*cm, 21 ft.*lbf)

(d) Install the rear seat headrest assembly RH.
HINT:
Check that the seat leg locks.

2. INSTALL REAR SEAT LEG SIDE GARNISH SUB-ASSEMBLY RH

(a) Install the rear seat leg side garnish sub-assembly RH.