REASSEMBLY

1. **INSTALL FRONT SEAT CUSHION SHIELD LOWER LH**
   (a) Install the front seat cushion shield lower LH.
2. **INSTALL FRONT SEAT CUSHION SHIELD LOWER RH**
3. **INSTALL RECLINING ADJUSTER INSIDE COVER LH**
   (a) Install the reclining adjuster inside cover LH (upper) with the screw.
4. **INSTALL RECLINING ADJUSTER INSIDE COVER RH**
   HINT:
   Use the same procedures for the RH side and LH side.
5. **INSTALL RECLINING ADJUSTER INSIDE COVER LH**
   (a) Install the reclining adjuster inside cover LH (lower) with the screw.
6. **INSTALL RECLINING ADJUSTER INSIDE COVER RH**
   HINT:
   Use the same procedures for the RH side and LH side.



7. **INSTALL SEPARATE TYPE FRONT SEAT CUSHION COVER**
   (a) Install the seat cushion pad to the seat cushion cover.
   (b) Using hog ring pliers, install the seat cushion cover to the seat cushion pad with new hog rings.
   NOTICE:
   - **Be careful not to damage the cover.**
   - **When installing the hog rings, take care to prevent wrinkles as much as possible.**



8. **INSTALL FRONT SEATBACK COVER RH**
   (a) Install the seatback pad.
   (b) Cover the top of the seatback pad with the seatback cover.
   (c) Using hog ring pliers, completely install the seatback cover with new hog rings.
   NOTICE:
   - **Be careful not to damage the cover.**
   - **When installing the hog rings, take care to prevent wrinkles as much as possible.**

SE



   (d) with Side airbag:
   Install the seatback cover bracket with the nut.
   Torque: 5.5 N*m (56 kgf*cm, 48 in.*lbf)
   NOTICE:
   - **For a vehicle with side airbag, the side airbag may not be activated normally unless the seatback cover is securely installed.**
   - **Check that the strap has no twist after installing the bracket.**



(e) Attach a rubber wire with new hog rings, as shown in the illustration.
(f) Using hog ring pliers, install new hog rings.
NOTICE:
- **Be careful not to damage the cover.**
- **When installing the hog rings, take care to prevent wrinkles as much as possible.**

9. INSTALL FRONT SEAT HEADREST SUPPORT
(a) Install the 2 headrest supports.

10. INSTALL FRONT SEAT HINGE COVER LH
(a) Install the seat hinge cover.

11. INSTALL FRONT SEAT HINGE COVER RH
(a) Install the seat hinge cover.

12. INSTALL FRONT SEATBACK LOCK SUB-ASSEMBLY RH
(a) Install the seatback lock assembly with 2 bolts.
Torque: 43 N*m (439 kgf*cm, 32 ft.*lbf)

13. INSTALL FRONT SEATBACK LOCK SUB-ASSEMBLY LH
(a) Install the seatback lock assembly with 2 bolts.
Torque: 43 N*m (439 kgf*cm, 32 ft.*lbf)

14. INSTALL FRONT SEATBACK SPRING ASSEMBLY
(a) Install the seatback spring assembly with 4 bolts.
Torque: 43 N*m (439 kgf*cm, 32 ft.*lbf)

15. INSTALL FRONT SEATBACK BOARD RH
(a) Install front seatback board RH.
(b) Install the clips.

16. INSTALL FRONT SEAT BACK SHIELD LH
(a) Install the seatback shield.
(b) Install the reclining adjuster release handle.

17. INSTALL FRONT SEAT INNER RH ARMREST ASSEMBLY
(a) Install the armrest assembly with the bolt.
Torque: 20 N*m (200 kgf*cm, 14 ft.*lbf)
(b) Install the armrest cap.

18. INSTALL FRONT SEAT TRACK COVER RH FRONT OUTER
(a) Install the seat track cover front outer with the clip and 2 screws.

19. INSTALL FRONT SEAT TRACK COVER RH FRONT INNER
(a) Install the seat track cover front inner with the clip and 2 screws.

20. INSTALL FRONT SEAT CUSHION SHIELD RH
(a) Install the cushion shield.
(b) Install the screw.

21. INSTALL RECLINING ADJUSTER RELEASE HANDLE RH

(a) Install the reclining adjuster release handle.

22. INSTALL FRONT SEAT INNER BELT ASSEMBLY RH

(a) Install the inner belt assembly with the nut.
Torque: 42 N*m (428 kgf*cm, 31 ft.*lbf)
HINT:
Check that the inner sat belt assembly moves smoothly.

(b) Connect the connectors.

23. INSTALL FRONT SEAT CUSHION SHIELD INNER RH

(a) Install the cushion shield inner.

(b) Install the screw.

24. INSTALL OCCUPANT CLASSIFICATION ECU (See page RS-488)

INSTALLATION

1. **INSTALL FRONT SEAT ASSEMBLY RH**
   (a) Place the seat assembly in the cabin.
   NOTICE:
   Be careful not to damage the body.
   (b) Connect the connectors under the seat assembly.
   (c) Tighten the 2 bolts on the front side of the seat assembly.
   Torque: 37 N*m (375 kgf*cm, 27 ft.*lbf)
   (d) Tighten the 2 bolts on the rear side of the seat assembly.
   Torque: 37 N*m (375 kgf*cm, 27 ft.*lbf)
   (e) Install the 2 track covers.
2. **INSTALL FRONT SEAT HEADREST ASSEMBLY**
3. **CHECK SRS WARNING LIGHT**
   HINT:
   See page RS-14
4. **CHECK SEAT SLIDE ADJUSTER LOCKS (See page SE-17)**
5. **INITIALIZE OCCUPANT CLASSIFICATION SYSTEM**
   HINT:
   See page RS-14