INSTALLATION

1. **INSTALL SEAT MEMORY SWITCH**
2. **INSTALL FRONT DOOR TRIM BOARD SUB-ASSEMBLY LH**
3. **INSTALL POWER WINDOW REGULATOR MASTER SWITCH ASSEMBLY**
4. **INSTALL FRONT DOOR INSIDE HANDLE BEZEL PLUG LH**
5. **INSTALL FRONT DOOR LOWER FRAME BRACKET GARNISH LH**
   (a) Engage the 4 claws to install the seat memory switch.

