CUSTOMIZE PARAMETERS

HINT:
The following items can be customized.
NOTICE:

- **After confirming whether the items requested by the customer are applicable or not for customization, perform the customize operation.**
- **Be sure to record the current settings before customizing.**
- **When troubleshooting, make sure that the item in question is not set to "OFF" as a result of customization.**

Power slide door ECU LH/RH:

DISPLAY (ITEM)	DEFAULT	CONTENTS	SETTING
PSD SW OPER	0.8s	Function that turns satellite switch ON when switch is pressed for specified time	0.8s/0.0s*1
PSD BUZZ VOL	OFF	Function that adjusts volume of warning buzzer that notifies power slide door is operating	OFF / SMALL / LARGE
WIRELS PSD OPER	0.8sPR	Function that operates power slide door when transmitter switch is pressed in specified way (1-press, 2-presses, 0.8 sec.-press or OFF*2)	1TIME / 2TIMES / 0.8secPR / OFF*2

*1 "0.0s" appearing on the display of the intelligent tester means that a 1-press of the satellite switch operates the power slide door.

*2 Wireless (transmitter switch) operation of the power slide door is disabled.

INITIALIZATION

1. RESET

(a) When the control motor and clutch is replaced:
The power slide door ECU cannot receive a switch signal from the control motor and clutch. This may cause the power slide door system to enter fail-safe mode and DTC (B2224 (LH) or B2223 (RH)) to set, and also make the system disabled.
When the motor and clutch is replaced, be sure to perform the following: first, properly connect the motor and clutch; second, clear the DTC using the intelligent tester and finally recheck that no DTC is output.

(b) Reset the power slide door system:
The power slide door ECU records the fully open position of the power slide door in its memory and the power slide door fully opens and closes based on this memory. The power slide door cannot operate without this memory. In the case where the battery has been removed, manually close the slide door fully to reset the power slide door system. However, if the battery is removed / installed when the slide door is fully open, the power slide door operates normally, thus the resetting the system is unnecessary.