INITIALIZATION

1. RESET

(a) Reset the power slide door system:
The power slide door ECU records the fully open position of the power slide door in its memory and the power slide door fully opens and closes based on this memory. The power slide door cannot operate without this memory. In the case where the battery has been removed, manually close the slide door fully to reset the power slide door system. However, if the battery is removed / installed when the slide door is fully open, the power slide door operates normally, thus the resetting the system is unnecessary.

PROBLEM SYMPTOMS TABLE

SLIDE DOOR CLOSER SYSTEM

Symptom	Suspected Area	See page
Slide door closer LH does not operate (*1)	1 ECU-B fuse	ED-99
	2. Power slide door lock assembly LH	ED-99
	3. Power slide door ECU LH	ED-99
	4. Wire harness	ED-99
Slide door closer RH does not operate	1 ECU-B fuse	ED-104
	2. Power slide door lock assembly RH	ED-104
	3. Power slide door ECU RH	ED-104
	4. Wire harness	ED-104
Slide door closer LH does not operate (*2)	1 L-PSD fuse	-
	2. Power slide door lock assembly LH	ED-258
	3. Slide door closer relay LH	-
	4. Wire harness	-

HINT:

- *1: with Power Slide Door
- *2: without Power Slide Door