PROBLEM SYMPTOMS TABLE

POWER SLIDE DOOR SYSTEM

Symptom	Suspected Area	See page
Power slide door LH does not operate when switch* is pressed (* switch indicates satellite switch for power slide door LH and power slide door control switch LH)	1. ECU-B fuse	ED-31
	2. Power slide door main switch	ED-31
	3. Satellite switch	ED-31
	4. Power slide door control switch LH	ED-31
	5. Power slide door touch sensor LH	ED-31
	6. Fuel lid courtesy switch	ED-31
	7. Power slide door motor and clutch LH	ED-31
	8. Power slide door lock assembly LH	ED-31
	9. Slide door release actuator assembly LH	ED-31
	10. Power slide door ECU LH	ED-31
	11. Driver Side J/B assembly (Multiplex network body ECU)	ED-31
	12. Wire harness	ED-31
Power slide door RH does not operate when switch* is pressed (* switch indicates satellite switch for power slide door RH and power slide door control switch RH)	1. ECU-B fuse	ED-49
	2. Power slide door main switch	ED-49
	3. Satellite switch	ED-49
	4. Power slide door control switch RH	ED-49
	5. Power slide door touch sensor RH	ED-49
	6. Power slide door motor and clutch RH	ED-49
	7. Power slide door lock assembly RH	ED-49
	8. Slide door release actuator assembly RH	ED-49
	9. Power slide door ECU RH	ED-49
	10. Driver Side J/B assembly (Multiplex network body ECU)	ED-49
	11. Wire harness	ED-49
Power slide door LH does not operate when using inside / outside handle (normally operates when using switch*) (* switch indicates satellite switch for power slide door LH and power slide door control switch LH)	1. Power slide door lock assembly LH	ED-65
	2. Handle operation detect switch LH	ED-65
	3. Child protection detect switch LH	ED-65
	4. Fuel lid switch	ED-65
	5. Power slide door ECU LH	ED-65
	6. Wire harness	ED-65
Power slide door RH does not operate when using inside / outside handle (normally operates when using switch*) (* switch indicates satellite switch for power slide door RH and power slide door control switch RH)	1. Power slide door lock assembly RH	ED-69
	2. Handle operation detect switch RH	ED-69
	3. Child protection detect switch RH	ED-69
	4. Power slide door ECU RH	ED-69
	5. Wire harness	ED-69
Jam protection function is activated while power slide door LH is operating. (for some reasons*) (* It may be caused by ill-fitting slide door, faulty touch sensor or faulty pulse sensor)	1. Fitting condition of slide door	ED-73
	2. Power slide door touch sensor LH	ED-73
	3. Power slide door motor and clutch LH	ED-73
	4. Power slide door ECU LH	ED-73
	5. Wire harness	ED-73
Jam protection function is activated while power slide door RH is operating. (for some reasons*) (* It may be caused by ill-fitting slide door, faulty touch sensor or faulty pulse sensor)	1. Fitting condition of slide door	ED-78
	2. Power slide door touch sensor RH	ED-78
	3. Power slide door motor and clutch RH	ED-73
	4. Power slide door ECU RH	ED-78
	5. Wire harness	ED-78
Power slide door does not fully open (stops operation at approx. 105 mm from fully open position)	1. Slide door half stop control	ED-83
	2. Power window regulator	ED-83
	3. Slide door half-open stopper cable	ED-83

Symptom	Suspected Area	See page
Power slide door warning buzzer LH does not sound	1. Power slide door warning buzzer LH	ED-85
	2. Power slide door ECU LH	ED-85
	3. Wire harness	ED-85
Power slide door warning buzzer RH does not sound	1. Power slide door warning buzzer RH	ED-88
	2. Power slide door ECU RH	ED-88
	3. Wire harness	ED-88