INITIALIZATION

1. RESET

(a) When the battery is reconnected:
The back door is locked and therefore cannot be opened. Therefore, it is necessary to unlock the back door using the door control switch or transmitter switch.

(b) Reset the power back door system:
The power back door ECU records the fully open position and the fully closed position of the power back door in its memory and the power back door fully opens and closes based on this memory. The power back door cannot operate without this memory. In the case where the battery has been removed, manually close the back door fully to reset the power back door system. However, if the battery is removed / installed when the back door is fully open, the power back door operates normally, thus the resetting the system is unnecessary.

PROBLEM SYMPTOMS TABLE

BACK DOOR CLOSER SYSTEM

Symptom	Suspected area	See page
Back door closer does not operate	1. Back door lock assembly	ED-119
	2. Power back door ECU	ED-119
	3. Wire harness	ED-119