CUSTOMIZE PARAMETERS

HINT:
The following items can be customized.
NOTICE:

- **After confirming whether the items requested by the customer are applicable or not for customization, perform the customize operation.**
- **Be sure to record the current settings before customizing.**
- **When troubleshooting, make sure that the item in question is not set to "OFF" as a result of customization.**

Power Back Door ECU

DISPLAY (ITEM)	DEFAULT	CONTENTS	SETTING
PBD SW OPER	0.8s	Function that turns power back door switch ON when switch is pushed once or held down for 0.8 sec.	0.8s/ON
PBD BUZZ VOL	OFF	Function that adjusts volume of warning buzzer that notifies power slide door is operating	OFF / SMALL / LARGE
WIRELS PBD OPER	0.8s	Function that operates power back door when transmitter switch is pressed in specified way (1-press, 2-presses, 0.8 sec.-press or OFF*1)	ON / TWICE ON / 0.8s / OFF
PBD ASSIST CLS*2	ON	Function that helps power back door closing operation	ON / OFF
PBD ASSIST OPN*3	OFF	Function that helps power back door opening operation	ON / OFF

*1 Wireless (transmitter switch) operation of the power slide door is disabled.

*2 When this item is set to ON:
When the back door is fully open, manually moving the back door approximately 12 cm within 0.5 sec. in the direction that the back door closes activates the power back door system to automatically close.

*3 When this item is set to ON:
When the back door is fully closed, pulling the outside activates the power back door system to automatically open after the back door is unlatched.

INITIALIZATION

1. RESET

(a) When the back door lock is replaced:
The power back door ECU cannot receive a switch signal from the lock. This may cause the power back door system to enter fail-safe mode and DTC B2215 to set, and also make the system disabled. When the lock is replaced, be sure to perform the following: first properly connect the lock, second clear the DTC using the intelligent tester and finally recheck that no DTC is output.

(b) Reset the power back door system:
The power back door ECU records the fully open position and the fully closed position of the power back door in its memory and the power back door fully opens and fully closed based on this memory. The power back door cannot operate without this memory. In the case where the battery has been removed, manually close the back door fully to reset the power back door system. However, if the battery is removed / installed when the back door is fully open, the power back door operates normally, thus the resetting the system is unnecessary.
Replacing drive unit will also cause the memory of the door positions to be last. Therefore, in such a case resetting the system is necessary.
Reset the power back door system as follows:
(1) Fully close the power back door if opened.
(2) Check that the back door fully open and fully close.
- Unlock the power back door using the transmitter switch or the door control switch.
- Turn the ignition switch to the "OFF" position.
- Check that the power back door main switch is in the "ON" position.
- Check that the back door fully open and fully close by pushing the power back door satellite switch or PBD button briefly.

HINT:
The jam protection function is enabled through the above initialization procedure.