

CLUB - GTI

HOW TO INSTALL: a Cold Air Induction Feed

By Mark Gallon (aka Ramjet)



1. GTI INSIDE AIRBOX
Inside the GTi Airbox.



2. THE WEIRD MAS THINGY

The Weird MAS thingy (try squinting...trippy huh).



3. THE HOLE TO AIM FOR

Access to behind the bumper from the engine bay.



4. FEED THE HOSING IN LIKE THIS:
Removing the Indicator Lamp makes it soooo much.



5. SPEEDFLEX SFS 82 HOSING
Feeding from the top is best and cut to length.



6. BEHIND THE VENT IN THE BUMPER

Pull the hosing around the guard & it should come out here.



7. THANK GOD FOR CABLE TIES

As per Andrew's hints, The Mighty Cable ties saves the day!



8. CUT YOUR LENGTH FEED IN AIRBOX

Cut to length. Feed into the airbox, pull it tight and trim.



9. START PUTTING IT BACK TOGETHER

Trimming the ends may require Selastic to help make it tidy.



10. ALL PUT BACK TOGETHER

Job looks neat, and clear tubing is good for checking for dirt.