

CHRYSLER PACIFICA STARTER #2 Wire Diagram using #775 Relay and 180 Ohm Resistor:

Starter # 2 wire is a PURPLE/BROWN at the Ignition Switch Harness

