



INSTALLATION

1. INSTALL ROOF DRIP SIDE FINISH MOULDING CLIP

NOTICE:

Only when exchanging the clips.

- (a) Remove the adhesive tape that remains on the moulding surface of the body, and then clean the surface with white gasoline.
- (b) Heat up the clip installation surfaces of the body with a heat light.

Body: 40 – 60 °C (104 – 140 °F)

Moulding: 20 – 30 °C (68 – 86 °F)

NOTICE:

Do not heat the moulding excessively.

- (c) Set the supplied clips into the positions as shown in the illustration, and press-fit those clips by hand to install them.
- (d) The installation of the moulding should be carried out when 30 minutes or more has passed after press-fitting the clips.

HINT:

- Initial hardening time: 30 minutes
- Perfect hardening time: 24 hours

2. INSTALL MOULDING