

INSTALLATION

1. **INSTALL CENTER STOP LIGHT ASSEMBLY**
2. **INSTALL REAR SPOILER SUB-ASSEMBLY**
 - (a) Install the rear spoiler with the 3 clips.
 - (b) Install the 5 bolts.
Torque: 9.8 N*m (99 kgf*cm, 87 in.*lbf)
 - (c) Connect the stop light connector.
3. **INSTALL BACK DOOR TRIM COVER (w/ Power Back Door)**
4. **INSTALL BACK WINDOW PANEL TRIM UPPER**
5. **INSTALL BACK DOOR TRIM BOARD (w/ Power Back Door)**

