

INSTALLATION

1. REMOVE ROOF DRIP SIDE FINISH MOULDING CENTER

NOTICE:

Only when exchanging clips.

- (a) Remove the tape that remains on the mounting surface of the body and then clean the surface with white gasoline.
- (b) Using a heat light, heat up the clip installation surfaces of the body and moulding.

Heating temperature

Body	Moulding
40 - 60°C(104 - 140°F)	20 - 30°C(68 - 86°F)

NOTICE:

Do not heat the moulding and body excessively.

- (c) Set the supplied clips in the positions as shown in the illustration and press-fit those clips by hand to install them.

NOTICE:

The installation of the moulding should be carried out when 30 minutes or more have passed after press-fitting the clips.

HINT:

- Initial hardening time: 30 minutes
- Required time for complete hardening time: 24 hours

