

Towing Procedures For Vehicles Without Front Tow-Hooks

1. The vehicle can be towed by hooking at the transverse links, as illustrated.
2. When starting to tow, accelerate gradually to avoid a sudden impact to the vehicle body. This prevents vehicle body parts from being deformed/damaged.
3. After towing, a Subaru dealer should inspect the affected portion of the body to check for damage/deformation of the parts.

