

Jumper harness needed from kit P# 24036AA010 for on the car reprogramming

Connect the Green Test mode connectors for ECM reprogramming
 Disconnect the Green Test mode connectors for TCM reprogramming

MY	Reprogramming	Legacy/Outback				Baja		WRX/Impreza/STI			Forester	
		2.5L NA	PZEV	2.5 Turbo	3.0L H-6	2.5L NA	2.5L Turbo	2.0L Turbo	2.5L NA	2.5L Turbo	2.5L NA	2.5L Turbo
00MY	ECM	Jumper not needed							Jumper not needed		Jumper not needed	
	TCM											
01MY	ECM	Jumper not needed			E/G -1				Jumper not needed		Jumper not needed	
	TCM											
02MY	ECM	E/G-2			E/G-2			E/G -1	Jumper not needed		Jumper not needed	
	TCM	AT			AT							
03MY	ECM	Jumper not needed			E/G-2	Jumper not needed		E/G-2	E/G-2		E/G-2	
	TCM	AT			AT	AT		AT	AT		AT	
04MY	ECM	Jumper not needed	E/G-2		E/G-2	Jumper not needed	Jumper not needed	E/G-2	Jumper not needed	Jumper not needed	Jumper not needed	Jumper not needed
	TCM	AT	AT		AT	AT	Jumper not needed	AT	AT		AT	Jumper not needed
05MY	ECM	Jumper not needed	Jumper not needed	Jumper not needed	Jumper not needed	Jumper not needed	Jumper not needed	E/G-2	Jumper not needed	Jumper not needed	Jumper not needed	Jumper not needed
	TCM	Jumper not needed	Jumper not needed	Jumper not needed	Jumper not needed	AT	Jumper not needed	AT	Jumper not needed		Jumper not needed	Jumper not needed

E/G -1

E/G-2

AT

Harness	
Marking	
E/G-1	3-pin connector 2 terminals
E/G-2	6-pin connector 4 terminals
AT	6-pin connector 4 terminals

