

BACK DOOR GLASS INSTALLATION

B03GE-01

HINT:

Install the glass and weatherstrip in the same manner as the windshield.

1. **CLEAN BODY AND GLASS**
2. **INSTALL WEATHERSTRIP ON GLASS**
3. **INSTALL BACK DOOR GLASS**
4. **FIX IN GLASS**
5. **APPLY ADHESIVE**
Part No. 08833-00030 or equivalent
6. **CLEAN SEALER SURFACE**
7. **INSPECT FOR LEAKS AND REPAIR**
Part No. 08833-00030 or equivalent
8. **CONNECT DEFOGGER WIRE CONNECTORS**

Connect the connector to the glass.

9. **CONNECT WIPER ARM**
Torque: 5.4 N·m (55 kgf·cm, 48 in.·lbf)