




FRONT FENDER FRONT APRON (ASSY)	 F14832-A
REPLACEMENT With the radiator side support removed.	

REMOVAL




POINT
1 Remove the [A] at the same time.

PART NAME
[A] Front Fender Apron Wind Guide Gusset

INSTALLATION

- Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
- Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
- After welding, apply the polyurethane foam to the corresponding parts.
- After welding, apply body sealer and under-coating to the corresponding parts.
- After applying the top coat layer, apply anti-rust agent to the inside of the necked section structural weld spots.



F20657

PART NAME

[A] Front Fender Apron Wind Guide Gusset

[B] Front Fender Apron Front Reinforcement (RH Only)

6 mm (0.24 in.)

20 mm (0.79 in.)