760TY–01

REPLACEMENT

1. REMOVE FRONT BUMPER BAR

(a) Disconnect the fog light connectors.

(b) Remove the 6 borts and bumper bar.

2. INSTALL FRONT BUMPER BAR

(a) Install the bumper bar with the 6 bolts.
Torque: 18 N·m (185 kgf·cm, 13 ft·lbf)

(b) Connect the fog light connectors.