

## INSTALLATION

### 1. INSTALL ROOF DRIP SIDE FINISH MOULDING CLIP

If the roof drip side finish moulding clip comes off.

- (a) Using a heat light, heat the body mounting surface to 40 - 60 °C (104 - 140 °F).

**NOTICE:**

**Do not heat the body excessively.**

- (b) Remove the adhesive tape and adhesive from the body.  
(c) Wipe off stains with cleaner.  
(d) Using a heat light, heat the body and clip.

**Body: 40 - 60 °C (104 - 140 °F)**

**Clip: 20 - 30 °C (68 - 86 °F)**

**NOTICE:**

**Do not heat the body and clip excessively.**

- (e) Install the clip.  
(f) Use the same manner described above to the other side (the front or rear side).

### 2. INSTALL ROOF DRIP SIDE FINISH MOULDING