

INSTALLATION

1. INSTALL NO.2 ROOF DRIP SIDE FINISH MOULDING CLIP

If the No.2 roof drip side finish moulding clip comes off.

- (a) Using a heat light, heat the body mounting surface to 40 – 60 °C (104 – 140 °F).

NOTICE:

Do not heat the body excessively.

- (b) Remove the adhesive tape and adhesive from the body.
(c) Wipe off stains with cleaner.
(d) Using a heat light, heat the body and clip.

Body: 40 – 60 °C (104 – 140 °F)

Clip: 20 – 30 °C (68 – 86 °F)

NOTICE:

Do not heat body and moulding excessively.

- (e) Install the clip.

2. INSTALL NO.2 ROOF DRIP SIDE FINISH CENTER MOULDING

Install the No.2 roof drip side finish center moulding to the roof drip side finish moulding.

3. INSTALL ROOF DRIP SIDE FINISH MOULDING