

INSTALLATION

1. INSTALL NO. 2 ROOF DRIP SIDE FINISH MOULDING CLIP

If the No. 2 roof drip side finish moulding clip comes off.

- (a) Using a heat light, heat the body mounting surface to 40 – 60 °C (104 – 140 °F).

NOTICE:

Do not heat the body excessively.

- (b) Remove the adhesive tape and adhesive from the body.
(c) Wipe off stains with cleaner.
(d) Using a heat light, heat the body and clip.

Body: 40 – 60 °C (104 – 140 °F)

Clip: 20 – 30 °C (68 – 86 °F)

NOTICE:

Do not heat the body and clip excessively.

- (e) Install the clip.

2. INSTALL NO. 2 ROOF DRIP SIDE FINISH CENTER MOULDING

Install the No. 2 roof drip side finish center moulding to the roof drip side finish moulding.

3. INSTALL ROOF DRIP SIDE FINISH MOULDING