

INSTALLATION

HINT:

Install the glass and weatherstrip in the same manner as the windshield.

1. **CLEAN BODY AND GLASS**
 2. **INSTALL WEATHERSTRIP ON GLASS**
 3. **INSTALL BACK DOOR GLASS**
 4. **FIX IN GLASS**
 5. **APPLY ADHESIVE**
Part No. 08833-00030 or equivalent
 6. **CLEAN SEALER SURFACE**
 7. **INSPECT FOR LEAKS AND REPAIR**
Part No. 08833-00030 or equivalent
 8. **CONNECT DEFOGGER WIRE CONNECTORS**
- Connect the connector to the glass.
9. **CONNECT WIPER ARM**
Torque: 5.4 N·m (55 kgf·cm, 48 in·lbf)