100BW–01

REPLACEMENT

1. REMOVE INTERCOOLER ASSY (See page 13–11)

2. REMOVE VENTURI ASSY

(a) Disconnect the throttle control motor connector.
(b) Remove the wire clamp bolt from the bracket.
(c) Disconnect the throttle full switch connector.
(d) Remove the 4 bolts and wire clamp bracket.

3. INSTALL VENTURI ASSY

(a) Install a new gasket, wire clamp bracket and the throttle body with the 4 bolts.
Torque: 20 N·m (200 kgf·cm, 15 ft·lbf)
(b) Connect the throttle full switch connector.
(c) Install the wire clamp bolt to the bracket.
(d) Connect the throttle control motor connector.

4. INSTALL INTERCOOLER ASSY (See page 13–11)