
FRONT SIDE MEMBER (CUT-P)


F16139-A

REPLACEMENT
With the radiator side support and front crossmember removed.

REMOVAL




F16139

POINT
1 Rmove the [A] at the same time.

PART NAME
[A] Front Sidememeber Extension
20mm (0.79in.)

INSTALLATION

- Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
- Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
- After welding, apply the polyurethane foam to the corresponding parts.
- After welding, apply body sealer and under-coating to the corresponding parts.
- After applying the top coat layer, apply anti-rust agent to the inside of the necked section structural weld spots.



F16140

PART NAME

[A] Front Sidememeber Extension