
FRONT FENDER APRON EXTENSION (ASSY)



F21442-A

REPLACEMENT

With the radiator side support and front body outer pillar removed.

REMOVAL






F21442

INSTALLATION

- Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
- Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
- After welding, apply the polyurethane foam to the corresponding parts.
- After welding, apply body sealer and under-coating to the corresponding parts.
- After applying the top coat layer, apply anti-rust agent to the inside of the necked section structural weld spots.



F21443

POINT

1 Inspect the fitting of the front fender etc., before welding, since this affects the appearance of the finish.