
JEEP LIBERTY PARKING LIGHT Diagram:

If your Units Parking Light Output is a (+)POSITIVE use this Diagram:

PARKING LIGHT wire in vehicle Note** the resistance value can be 5% plus or minus this value, wattage and voltage of the resistor will not matter..... Resistor YELLOW WHITE not used **BROWN** or WHITE (+) **Parking** GROUND **Light Output** from Unit.

If your Units Parking Light Output is a (-) NEGATIVE use this Diagram:



Year and Model	Resistor Value	POLARITY and LOCATION
02-03 JEEP LIBERTY	1000 Ohm	(-) @ the PARKING LIGHT SWITCH
04-05 JEEP LIBERTY	910 Ohm	(-) @ LIGHT SWITCH or BCM GRAY 22 PIN, PIN 5