



NISSAN Starter #1 and Starter #2 Isolation Circuit

YELLOW/BLACK or PURPLE Starter/Crank wire from Remote Start

Requires (2) #775's



12V (+) Constant fused at 30 Amps



Starter #1 wire in Vehicle

Starter #2 wire in Vehicle