


FORD 5-Wire Trunk Release Diagram:

If your Unit has a (-) NEGATIVE Trunk Pop Output, use this diagram...



Using a (+) POSITIVE Trunk Pop Output:

